

AWNING WINDOWS

Table of Awning Window Sizes


Scale 1/8" (3) = 1'-0" (305) – 1:96

Window Dimension	1'-5 1/2"	1'-11 1/2"	2'-5 1/2"	2'-11 1/2"	3'-5 1/2"	3'-11 1/2"
	(445)	(597)	(749)	(902)	(1054)	(1207)
Minimum Rough Opening	1'-6"	2'-0"	2'-6"	3'-0"	3'-6"	4'-0"
	(457)	(610)	(762)	(914)	(1067)	(1219)
Unobstructed Glass	11 1/4"	17 1/4"	23 1/4"	29 1/4"	35 1/4"	41 1/4"
	(286)	(438)	(591)	(743)	(895)	(1048)

CUSTOM HEIGHTS – 1'-5 1/2" to 2'-11 1/2"	CUSTOM WIDTHS – 1'-5 1/2" to 3'-11 1/2"								
	1'-5 1/2"	1'-11 1/2"	2'-5 1/2"	2'-11 1/2"	3'-5 1/2"	3'-11 1/2"			
1'-5 1/2"	(445)	1'-6" (457)	11 1/4" (286)	1616	2016	2616	3016	3616	4016
1'-11 1/2"	(597)	2'-0" (610)	17 1/4" (438)	1620	2020	2620	3020	3620	4020
2'-5 1/2"	(749)	2'-6" (762)	23 1/4" (591)	1626	2026	2626	3026	3626	4026
2'-11 1/2"	(902)	3'-0" (914)	29 1/4" (743)	1630	2030	2630	3030	3630	4030



Custom-size windows are available in 1/8" (3) increments.



Choose venting or stationary. **Awning window must be installed to vent as shown and should not be rotated and used as a hopper.**


- "Window Dimension" always refers to outside frame to frame dimension.
- "Minimum Rough Opening" dimensions may need to be increased to allow for use of building wraps, flashing, sill panning, brackets, fasteners or other items.
- Dimensions in parentheses are in millimeters.

Custom Sizes & Specifications



100 Series custom-size windows are available in 1/8" (3) increments between minimum and maximum widths and heights shown. Some restrictions apply.


Awning Windows



Single


Clear Opening 	Width = window width - 5.694" (145) Height = 8.000" (203)	Minimum R.O. 	Width = window width + 1/2" (13) Height = window height + 1/2" (13)
Vent Opening 	Width = window width - 5.694" (145) Height = 8.000" (203)	Unostr. Glass 	Width = window width - 6.250" (159) Height = window height - 6.250" (159)

Twin



Clear Opening 	Width = (window width ÷ 2) - 5.944" (151) Height = 8.000" (203)	Minimum R.O. 	Width = window width + 1/2" (13) Height = window height + 1/2" (13)
Vent Opening 	Width = (window width ÷ 2) - 5.944" (151) Height = 8.000" (203)	Unostr. Glass 	Single Sash Width = (window width ÷ 2) - 6.50" (165) Total Sash Width = window width - 13.000" (330) Height = window height - 6.250" (159)

Picture over Awning



Clear Opening 	Width = window width - 5.694" (145) Height = 8.000" (203)	Minimum R.O. 	Width = window width + 1/2" (13) Height = window height + 1/2" (13)
Vent Opening 	Width = window width - 5.694" (145) Height = 8.000" (203)	Unostr. Glass 	Width = window width - 6.205" (159) Total Sash Height = window height - 13.000" (330) <i>For separate fixed and venting sash height unobstructed glass dimensions contact your Andersen supplier.</i>